PRECISION GRILL INSERTS INSTALLATION INSTRUCTIONS

09-C FORD F-150, REGULAR CAB, SUPER CAB & SUPER CREW

PART #371430 (Summer Kit)

- Before you install your Precision Grill Insert, see the diagrams and parts list for necessary parts.
- Your Precision Grill Insert has been cleaned and the edge trimming applied. It is ready to install as Diagram #1 indicates.
- Thread the thumbscrew onto the clip, Diagram #2, just far enough to allow the locknut to fit fully onto the thumbscrew. Back the clip up against the locknut. This will allow you to manipulate the clip easier.
- You will have to hand bend each of the outside ends of the upper & lower channels fully before manoeuvring into place.
- Position your grill insert using the thumbscrew / clip assembly through the truck grill. Pull the screw assembly out until the clip engages the truck grill, Diagram #2. Maintain a slight pull on the thumbscrew and turn clockwise, finger tighten until snug.
- You may find it easier to start at one end of the grill. Snug the first clip and work towards the other end. Once all of the clips are in place, snug them finger tight only.
- Precision Grill Inserts are designed to fit your truck. If they do not fit perfectly, they are installed incorrectly.
- If at anytime your engine overheats, remove the insert.

#371464 – PARTS BAG CONTENTS			
(20) Screw, #8x1-1/4 (16) 'J' 1.5" Clip	Part #016001 Part #370020	(20) Locknut, #8 (4) 'C' 1.5" Clip	Part #016002 Part #370021
STAINLESS STEEL PARTS			
(1) Top Grill(1) Bottom Grill(1) LH Grill	Part #371432 Part #371435 Part #371436	(1) Middle Top Grill (1) Middle Bottom Gr (1) RH Grill	

SEE DIAGRAMS ON PAGE 2.

Ford F150 **Winter** Grill Insert available from your Dealer - Part No. 371431 Ford **Bumper screens** also available from your Dealer!

PRECISION GRILL INSERTS INSTALLATION INSTRUCTIONS

09-C FORD F-150, REGULAR CAB, SUPER CAB & SUPER CREW

PART #371430 (Summer Kit)




