


IMPORTANT:


Manufacturer is not responsible for negligent use of vehicle with Filler Panel installed, including over-tightening of screws and bolts causing damage to vehicle or filler panel.

KIT INCLUDES

(1) Water Separator Guard
Part #702349



(1) Access Door
Part #702350



PARTS BAG #702351

a) (2) Capscrew, SS
1/4"-20UNC x 1"
Part #014007



b) (2) Washer, Flat, SS
0.281" x 1"
Part #018028



c) (1) Washer, Flat, Pltd
3/8" x 0.8"
Part #018046



d) (2) Washer, Lock, SS
1/4" Helical Sprint
Part #024000



e) (1) Washer, Lock, Pltd
3/8" Helicoil
Part #024006



f) (1) Nut, Hex, Pltd
3/8"-16UNC
Part #025015



g) (1) T-bolt
Universal
Part #762236



INSTALLATION INSTRUCTIONS

1. Before you install your water separator guard, see the diagram and parts list for all necessary parts.
2. Remove the three factory push pins and the factory water separator plastic guard from the water separator tank. See diagram #1.
3. Remove water separator sensor mount clip from the driver side frame.
4. Install the T-bolt in the factory slotted hole on the cross member channel with the bolt facing downward. See diagram #2.
5. Install the supplied water separator guard with the water separator sensor cable placed inside the guard. Carefully place the upper mount tab slotted hole of the guard to the t-bolt then fasten the t-bolt with a 3/8" flat washer, a 3/8" lock washer, and a 3/8" hex nut. See diagram #2. Loosely secure at this point.
6. Use the previously removed factory push pins and secure the supplied guard the same way in which the factory guard was secured. See diagram #2. Now secure the 3/8" hex nut on the t-bolt.
7. Slide the access door in between the two support tabs on the bottom of the guard, then bolt the access door with two 1/4" flat washers, two 1/4" lock washers and two 1/4" x 1" capscrews.

Diagram #1




Diagram #2

