



TAILGATE SKIN

PLEASE NOTE

Surface must be cleaned with Isopropyl or an alcohol base cleaner and free of any oils or dirt/dust prior to applying your trim with 3M tape. The recommended surface temperature for applying 3M tape is between 16-43°C (60-110°F).

Note: Always perform a 'Dry Fit' before peeling the 3M tape and applying the Tailgate Skin to the truck. Please be advised, we will not accept returns on plastic peeled products. We welcome & appreciate your comments on all of our products!

**Tailgate Skins are manufactured
with the finest stainless steel.**

**With proper maintenance and cleaning, your
Tailgate Skin will look great for years to come!**