

II-C, DODGE 3500/4500/5500 Cab + Chassis, Regular Cab Urea Tank Skid Playe Mounying Diagram PART # 700144

IMPORTANT:

Manufacturer is not responsible for negligent use of vehicle with Skid Plate installed, including over-tightening of screws and bolts causing damage to vehicle or Skid Plate.

INSTALLATION INSTRUCTIONS

(1) Skid Plate

Part # 701450

1. Loosen and remove the two factory hex bolts, #1, #2 (see picture 1, 2).

PARTS

2. Put the Skid Plate (PRECISION to the outside) in place; use the factory bolts to secure. Be sure you torque down both bolts!









Picture 2



IMPORTANT: Inspect factory bolts, ensure that they are tight! Inspect occasionally to ensure that they remain tight.