

IMPORTANT:

Manufacturer is not responsible for negligent use of vehicle with shifter linkage guard installed, including overtightening of screws and bolts causing damage to vehicle.

Kit Includes:

- (1) Shifter Linkage Guard
- (1) M8 Capscrew
- (1) Lock Washer



Remove M8 Factory Bolt from Shifter Linkage Bracket



Remove Air Breather Hose Clip from Transmission

Step 1: Remove Factory M8 Bolt and washer from Shifter Linkage Bracket.

Step 2: Remove Air Breather Hose Clip from Transmission.

Step 3: Move Guard into position, ensuring that the Air Breather Hose is tucked behind the guard, and reinstall Factory M8 Bolt and washer to Shifter Linkage Bracket through Guard.

Step 4: Install provided Bolt and Washer through guard to hole from which you removed the Clip from the Air Breather hose. Tighten both bolts.

Completed Install pictured below:

