




08-C FORD SD, CREWCAB, LB, SW # 760053

Qty.	Part#	Description	Qty.	Part#	Description
1	Assembled	Front Driver Side Bracket	4	014022	5/16" x 1" Cap Screw
1	Assembled	Front Passenger Side Bracket	2	018045	5/8" Flat Washer
1	Assembled	Middle Driver Side Bracket	28	018046	3/8" Flat Washer
1	Assembled	Middle Passenger Side Bracket	4	018047	5/16" Flat Washer
1	Assembled	Middle Rear Driver Side Bracket	4	024002	5/16" Lock Washer
1	Assembled	Middle Rear Passenger Side Bracket	2	024003	5/8" Lock Washer
1	Assembled	Rear Driver Side Bracket	28	024006	3/8" Lock Washer
1	Assembled	Rear Passenger Side Bracket	16	025015	3/8" Hex Nut
12	014012	3/8" x 1-1/2" Cap Screw	4	028005	Spring Nut, 5/16"-18 UNC Extended
2	014021	5/8" x 2" Cap Screw	21.25'	080407	Bulb Seal Push-On
			6	762236	3/8" x 1-1/2" T-bolt



Note Orientation of Bracket Flanges and Braces

Note: Start on Driver Side

ADJUSTABLE MOUNTS

Step 1: Remove front cab mount bolt and install pre-assembled bracket loosely with the factory bolt. Watch out for bracket orientation. Set up the front bracket support strap using #762236 T-Bolt with #018046 3/8" flat washer, #024006 3/8" lock washer and #025015 3/8" hex nut.

Step 2: For rear bracket, drill the factory hole to 5/8" to get the #762236 T-bolt in. Then repeat step 1 for rear bracket.

Step 3: Lay pre-assembled board on the rear bracket. Make sure board will not fall down. You should might use also a jack to avoid board from falling down. Line board up with the front bracket and set up #014021 5/8" cap screw with #018045 flat washer and #024003 5/8" lock washer. Do not tighten up the bolts, you need to level the board later.

Step 4: Remove any plastic wrap around bracket saddles.

Step 5: Use #014012 3/8" cap screw with #018046 flat washer and #024006 lock washer to install board to rear bracket loosely.

Step 6: Remove middle driver and middle rear cab mount bolt and install middle brackets with factory bolt loosely. Install board to brackets like you did with the rear bracket. Set up the middle bracket support strap using #028005 5/16" spring nut with #014022 5/16" cap screw and #024002 5/16" lock washer.

Step 7: Level board to Cab and tighten up the 6x #014012 cap screws. Secure all other bolts now.

Step 8: Repeat for Passenger Side.