




# GATORGEAR NERF BOARD TRUCK HARDWARE


Carton 1 of 2 – DS & PS Board Assembly  
760058: #760380 & 760588  
760077: #761008 & 761009  
Carton 2 of 2 - Bracket and Fastener Kit  
#760735

## 2013-18, DODGE HD 2500 / 3500 CREW CAB SB #760058 2019, DODGE HD 2500 / 3500 CREW CAB SB #760077

Qty.	Part#	Description	Qty.	Part#	Description
1	Assembled	Front Driver Side Bracket	2	018045	5/8" Flat Washer
1	Assembled	Front Passenger Side Bracket	14	018046	3/8" Flat Washer
1	Assembled	Middle Driver Side Bracket	2	024003	5/8" Lock Washer
1	Assembled	Middle Passenger Side Bracket	14	024006	3/8" Lock Washer
1	Assembled	Rear Driver Side Bracket	6	025015	3/8" Hex Nut
1	Assembled	Rear Passenger Side Bracket	16.75'	080407	Bulb Seal Push-On
8	014012	3/8" x 1-1/2" Cap Screw	6	762236	3/8" x 1-1/2" T-bolt
2	014021	5/8" x 2" Cap Screw			



### Dodge Crew Cab SB Adjustable Mount



**Note: Start on Driver Side**

**Step 1:** Remove front cab mount bolt and install pre-assembled bracket loosely with the factory bolt. Watch out for bracket orientation. Set up the front bracket support strap using #762236 T-Bolt with #018046 3/8" flat washer, #024006 3/8" lock washer and #025015 3/8" hex nut.

**Step 2:** Repeat process for rear bracket.

**Step 3:** Lay pre-assembled board on the rear bracket. Make sure board will not fall down. You should might use also a jack to avoid board from falling down. Line board up with the front bracket and set up #014021 5/8" cap screw with #018045 flat washer and #024003 5/8" lock washer. Do not tighten up the bolts, you need to level the board later.

**Step 4:** Remove any plastic wrap around bracket saddles.

**Step 5:** Use #014012 3/8" cap screw with #018046 flat washer and #024006 lock washer to install board to rear bracket loosely.

**Step 6:** Remove middle cab mount bolt and install middle bracket with factory bolt loosely. Install board to bracket like you did with the rear bracket. Set up the middle bracket support strap using #762236 T-Bolt with #018046 3/8" flat washer, #024006 3/8" lock washer and #025015 3/8" hex nut.

**Step 7:** Level board to Cab and tighten up the 4x #014012 cap screws. Secure all other bolts now.

**Step 8:** Repeat for Passenger Side.