


2022-C Ford Navigator Mud Flap Set, Stainless, Rear Mounting Diagram & Instructions

IMPORTANT:

Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.



INSTALLATION (For ease of installation it is suggested that the wheel be removed)

- 1. Before you install your Mud Flap Set, see the diagram and parts list for all necessary parts.
- 2. Remove the four factory push pins located on the inner fender.
- 3. Pull back the liner and install spring nuts (e) to the tabs that hold the liner in place.
- 4. Hold the mud flap in place and use a marker to mark about 1/4" above the mud flap.



- 5. Install durastrip (f) from the mark down the edge of the vehicle. This protects the paint and body from the mud flap.
- 6. Loosely install mud flap holes #1 to #4 to spring nuts (e) using a capscrew (a) and flat washer (b).
- 7. Push the mud flap hole #5 against the factory liner and drill a 1/4" hole through the mud flap hole into the factory liner.
- 8. Loosely install mud flap hole #5 to liner using a capscrew (a) and flat washer (b) and secure using a flat washer (b), lock washer (c) and hex nut (d).
- 9. Using a square or another levelling tool, ensure that the mud flap is level. Tighten all fasteners.
- 10. Repeat procedure on passenger side.

