




# GATORBACK MUDFLAPS

**2010-2018, Ram HD Dually**  
**2019-Current, Ram HD Dually without flare**  
**Mud Flap Set**  
**Mounting Diagram & Instructions**  
**For use with 19" Rubber**  
**GB768068**

### IMPORTANT:

**The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.**


### TOOLS REQUIRED




Electric or re-chargeable  
1/2" or 3/8" drill.



1/4  
drill bit




3/8" and 5/16" wrench  
and socket set




3/8" Socket Driver

### SCREWS / FASTENERS / WASHERS / FLAPS - PARTS BAG #768067


(1) SS Mount, DS  
Part #755530




(1) SS Mount, PS  
Part #755531



(1) Brkt, Z, DS  
Part # 750433



(1) Brkt, Z, PS  
Part #750434



e) (44) Washer, Flat  
0.203" x 1" 18ga  
Part #018081



f) (20) Screw Machine  
#10-24UNC x 1-1/2  
Part #012027



c) (20) Nut, Hex, SS  
#10  
Part #025003



d) (20) Lock Washer  
#10  
Part #024001



Note: 2010-2018 Models require less hardware than 2019-2020 Models.  
If you are installing on a 2010-2018 Model, you will have extra hardware

**Prior to installation of your Mud Flap, see the above diagrams and parts list for all necessary parts.  
Start on the driver side.**

### INSTALLATION

*For ease of installation, it is suggested that the wheel be removed.*

- Align bracket to rubber (purchased separately) as shown in Diagram #1. Drill 1/4" holes into rubber through bracket holes. Cut rubber to match bracket profile.
- Remove factory harness mounts A & B with harness and reinstall to the "Z" bracket holes C & D.
- Bolt the upper holes of the "Z" bracket to the existing factory push screw holes A & B with two machine screws, four flat washers, two lock washers and two hex nuts.
- Remove the factory screws #11 & #12 on the wheel flare as shown on the diagram and reinstall the two factory screws, with flat washers, on holes #1 and #2 through the factory holes #11 and #12.
- Drill a 1/4" hole (7 places) from holes #3 to #9 through the factory tub liner then fasten holes #3 and #4 through the factory tub liner into the "Z" bracket bottom holes with two machine screws, four flat washers, two lock washers & two hex nuts. For the remaining holes, fasten with 5 machine screws, 10 flat washers, 5 lock washers, and 5 hex nuts.
- 5a. For 2019-2020 models, drill a 1/4" hole from the back lower corner of the factory plastic molding through the rubber flap to create hole #10, and then secure the flap using a machine screw, two flat washers, a lock washer, and a hex nut.

✓ Check all fasteners for tightness. Repeat procedure on passenger side.

Diagram #1




Diagram #2

