



IMPORTANT:

The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.

TOOLS REQUIRED:




7/16" open wrench
and socket wrench




5/16" open wrench
or socket wrench



Slotted
Screw Driver




10mm open wrench
and socket wrench
(truck w/ flare only)




7/32" or 5.5mm open
or socket wrench
(truck w/o flare only)

BRACKETS


(2) Mount Bracket,
Front
Part #759843



(1) Brace
Front, DS
Part #759844



(1) Brace
Front, PS
Part #759845



(2) Strip Washer
Front
Part #759846




PARTS BAG #759853

a) (4) Capscrew, SS
1/4" - 20UNC x 3/4"
Part #014034



b) (6) Screw, Sheet Metal
SS, #12 x 1-1/2" HWH
Part # 010045




c) (2) Screw, Sheet Metal
ss, #12 x 1"
Part #010046




c) (4) Washer, Lock
SS, Helicoil
Part # 024000



e) (8) Washer, Flat
Aluminum, 0.281" x 1"
Part #018052




f) (8) Washer, Flat
SS, 0.281" x 1"
Part # 018028



g) (4) Flange Nut,
Serrated, M6
Part # 025025



h) (6) Washer, Nylon
1" OD x 0.318" ID
Part # 054061



i) (4) Nut, Hex
SS, 1/4" - 20UNC
Part # 025000



j) (9) Nut, Expansion
Nylon, Natural #12
Part # 054059



k) (2) Nylon Spacer
1/2" x 1/2", ID 1/4"
Part #054063



Installation:

1. Install the 4 nylon expansion nuts, #054059 into the mount bracket. Make sure all nuts are seated properly.
2. Attach the mount bracket to the brace with supplied hardware. Use the inside holes on the brace for trucks with OEM flares and the outside holes for trucks without.
3. Turn wheels to get access to wheel well where the flap will be installed.
4. Loosen screws that secure the fender liner to the fender edge.
5. On trucks with flares; remove the lower front screw.
6. Slide the outside edge of the bracket between the plastic fender liner and the metal edge of the fender, on the non-flare trucks.
Trucks with Flares: Install bracket between the flare and the aluminum fender lip.
7. Attach the back brace onto the two lower factory fender bolt using the supplied M6 flange nuts, #025025.
8. Reinstall lower front screw on trucks with flares.
9. All the loose fasteners can now be tightened.
10. Attach mud flap to bracket starting with the inside fasteners. Do not tighten completely, so you can still adjust / straighten the mud flap.
11. Position strip washer 759846 over top of flap and attach outside fasteners. Use nylon spacer #054041 on top position to fill void between mount bracket and strip washer. Move nylon spacer to desired location to distribute pressure of strip washer evenly on mud flap.
12. Make sure flap is mounted in the desired position and then hand tighten all the bolts. Make sure not to over tighten fasteners as the expansion nuts could be damaged.

✓ Check all fasteners for tightness. Repeat procedure on the passenger side.

Please check out our YouTube channel to see an install video for this application.



Installation Diagram with optional rubber

