



## **DOOR SILLS KITS**

### **PLEASE NOTE**

Surface must be cleaned with Isopropyl or an alcohol base cleaner and free of any oils or dirt/dust prior to applying your Door Sill with 3M tape. The recommended surface temperature for applying 3M tape is between 16-43°C (60-110°F).

***Note:** Always perform a 'Dry Fit' before peeling the 3M tape and applying the Door Sill to the truck. Please be advised, Precision will not accept returns on peeled Door Sills. We welcome & appreciate your comments on all of our products!*

**Door Sills are manufactured  
with the finest stainless steel.**

**With proper maintenance and cleaning, your  
Door Sill will look great for years to come!**