



Mud Flap Set

Universal, 14", 1.5" Offset

Mounting Diagram & Instructions

MUDFLAPS Part 756623 (Stainless Steel) / #756624 (Black)

IMPORTANT:

The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.


TOOLS REQUIRED:



Electric or re-chargeable
1/2" or 3/8" drill.



1/4" Drill bit




7/16" wrench
and socket set



3/8" Socket Driver

KIT CONTAINS: PARTS BAG #755133

a) (1) Upper Panel, DS
Part #755671



b) (1) Upper Panel, PS
Part #755672



c) (8) Tek Screw,
1/2" x 1/4", SS
Part #010011



d) (8) Washer, SS
0.203 x 1" OD
Part #018028



INSTRUCTIONS:

1. Before you install your upper mounts, see the Diagram #1 and parts list for all necessary parts. Start on the Driver's Side.
2. Square the flap with the tire while holding the flap up against the wheel well and the offset flange tuck underneath the wheel well. (See Diagram #3)
3. Locate the center of the wheel well or wheel flare on the back side of the stainless steel panel and drill four 1/4" holes from 'A' to 'D' on the stainless steel panel only.

Note: Drill with caution, do not drill through the wheel well or wheel flare.

4. Peel protective plastic away from the stainless steel.
5. Secure the flap with four flat washers and four tek screws on hole 'A' to 'D'.
9. Repeat procedure for the passenger side.

