



12" x 5/8" OFFSET
 Stainless Steel Mud Flap
 Mounting Diagram & Instructions
 2004-12 Ford F-150, Front, SS
 Part #756336

IMPORTANT:

Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, or over-tightening of screws and bolts causing damage to vehicle or mud flaps.

TOOLS REQUIRED

- | | | | | | |
|--|-----------------------|----------------------------------|--|--|---|
| <i>Electric or re-chargeable
1/2" or 3/8" drill.</i> | <i>1/4" drill bit</i> | <i>Robertson
Screwdriver</i> | <i>5/16" & 3/8" open end wrench
or socket wrench</i> | 
<i>3/8" Socket
Driver</i> | <i>7/32" open end wrench
or socket wrench</i> |
|--|-----------------------|----------------------------------|--|--|---|

FLAPS -

*(1) Flap Assembly,
Front, LH, DS*



*(1) Flap Assembly,
Front, RH, PS*



PARTS BAG #750247


- | | | |
|--|---|--|
| <i>a) (6) Screw, Tek
1/4" x 1-1/4"
Part # 010011</i> | <i>b) (4) Screw, Sheet Metal
#10 x 1-1/4"
Part #010017</i> | <i>c) (2) Screw, Machine
#10 x 1"
Part # 012022</i> |
| <i>d) (4) Washer, Flat
0.281 x 1" x 18ga, SS
Part #018028</i> | <i>e) (2) Washer, Half
0.281 x 1" x 18ga, SS
Part #018029</i> | <i>f) (6) Washer, Flat
0.203 x 1" x 18ga, SS
Part # 018031</i> |
| <i>g) (2) Washer, Half
0.203 x 1" x 18ga, SS
Part # 018032</i> | <i>h) (2) Washer, Lock
18-8SS, #10 Helicoil
Part # 024001</i> | <i>i) (2) Nut, Hex
#10, SS
Part # 025003</i> |


Before you install your Gatorback Mud Flaps, see the above diagrams and parts list for all necessary parts. Cut the protective plastic and peel away from Stainless Steel. Start on the driver's side.

INSTALLATION

Important: Manufacturer is not responsible for negligent use of vehicle with mud flap installed, or over tightening of screws and bolts causing damage to vehicle of mud flaps.

1. Remove two factory screws on the wheel flare #7 & #8 as shown on the diagram and discard. Install two sheet metal screws and washers from holes #5 & #6 through previously drilled holes #7 & #8. Loosely secure at this point.
2. Square the flap with the tire and push the flap up against the wheel well then tighten the two factory screws on holes #5 & #6.
3. Fasten the flap with three tek screws and washers on hole #3, #2, and then #1.
4. Drill a 1/4" hole from hole #4 through the factory plastic guard and fasten hole #4 with a machine screw, washers, lock washer, and hex nut.





✓ Check all fasteners for tightness. Repeat procedure on the passenger side

MAINTENANCE TIPS

Rubber Care

Maintaining your rubber mud flaps is the same as looking after your tires. Use soap and water to remove road dirt and debris and then clean rubber with any good rubber weather/wear protector that you would use on your tires. All Mud Flaps are made from new virgin rubber, for long lasting great looks.

Stainless Steel Care

Keeping your mud flaps looking great requires proper care to be taken with your stainless steel - the same care that you would take to look after the paint on your truck. High amounts of salt will deteriorate even the finest stainless steel if it is continuously abused. Wash the stainless steel on your mud flaps from time to time to remove any road grime or salt. To shine, use window cleaner to remove any spots or streaks.