



1223CUT, 5/8" OFFSET
Stainless Steel Mud Flap
Mounting Diagram & Instructions
2009-C Dodge 1500 & 2010-C H.D., Rear
Part 756247

IMPORTANT:

Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.

TOOLS REQUIRED




Electric or re-chargeable
1/2" or 3/8" drill.



5/16" socket driver




1/4" drill bit




5/16" and 3/8" wrench
or socket wrench

SCREWS / FASTENERS / WASHERS / FLAPS: PARTS BAG #755563

a) (1) Flap Assembly, 09-C
Rear, PS 12"



b) (1) Flap Assembly, 09-C
Rear, DS 12"



c) (2) Screw, TEK, 410 SS
#10 x 1", HWH
Part #010009



d) (6) Screw, Machine 18-8SS
#10-24x1" Hex HD
Part # 012022



e) (14) Washer, Flat,
0.203 x 1" flat 18ga. SS
Part #018031



f) (6) Washer, Lock
#10
Part #024001



g) (6) Nut, Hex
SS, #10
Part #025003



**Before you install your Mud Flap, see the above diagrams and parts list for all necessary parts.
Start on the driver's side.**


INSTALLATION

For ease of installation, it is suggested that the wheel be removed.

1. Before installation, peel protective plastic covering from the stainless steel panels. See the diagram and parts list for all necessary parts. Start on the Driver's side.
2. Remove two (2) factory screws on the wheel flare or wheel well as shown on the diagram and reinstall the two (2) factory screws on hole #1 and #3 through the factory holes #7 & #8, loosely secure at this point.
3. Square the flap with the tire while putting pressure on the wheel well or wheel flare. Be sure that flap is straight.
4. Now tighten the two (2) factory screws on holes #1 & #3. Then secure the flap with a tek screw, #010009, and a flat washer, #018031, on hole #2. Do not over tighten.



5. Drill ¼” hole (3) from hole #4 to #6 through the factory plastic liner and secure those holes with three (3) machine screws, #012022, six (6) flat washers, #018031, three (3) lock washers, #024001 and three (3) hex nuts, #025003.
6. Repeat this procedure for the passenger side.



Check all fasteners for tightness. Repeat procedure on the passenger side

MAINTENANCE TIPS

Rubber Care

Maintaining your rubber mud flaps is the same as looking after your tires. Use soap and water to remove road dirt and debris and then clean rubber with any good rubber weather/wear protector that you would use on your tires.

Stainless Steel Care

Keeping your mud flaps looking great requires proper care to be taken with your stainless steel - the same care that you would take to look after your paint on the truck. High amounts of salt will deteriorate even the finest stainless steel if it is continuously abused. Wash the stainless steel on your mud flaps from time to time to remove any road grime or salt. To shine, use window cleaner to remove any spots or streaks.