

RAZORBACK MUDFLAPS

2019-C Ram 1500 New Body

No Body Drill Rubber Mud Flap Set, Rear Mounting Diagram & Instructions


Kit's # RCR34R

IMPORTANT:


Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.



TOOLS REQUIRED



5/16 & 3/8" Open End
Wrench & Socket Wrench




Electric or Chargeable
Drill




1/4" Drill Bit

FLAPS

(1) Flap Assembly,
Rear, DS



(1) Flap Assembly,
Rear, PS



PARTS BAG # 766782

a) (6) Washer, Flat
0.203" x 1", SS
Part #018081



b) (2) Washer, Lock
#10, Helicoil, SS
Part #024001




c) (2) Hex Nut
#10, SS
Part #025003




d) (2) Mach. Screw
#10-24 x 1", SS
Part #012022



e) (2) Bolt, Hex Flange
M4.2 x 1", SS
Part #016041



f) (8) Washer, Flat, SS
0.203" x 1.5", 18ga
Part #018066




g) (2) Spring Nut
#8, 9/16" Reach
Part #028004




INSTALLATION

Note Please see mounting diagram for important details regarding with flare and without flare applications. For ease of installation, it is suggested that the wheel be removed.

1. Before you install your Gatorback Mud Flap, see the diagram and parts list for all necessary parts.
2. Remove the 3 factory bolts from holes #7 to #9 in the fender.
- 3a. For trucks with OE flare, install mud flap into factory fender holes #7 to #9 through mud flap holes #1 to #3 using factory screws and supplied 1-1/2" washers (018066), and into plastic liner hole #10 through mud flap hole #4 using a factory screw and a supplied 1" washer (018031). Loosely secure at this point.
- 3b. For trucks without flare, install mud flap into factory fender holes #7 to #9 through mud flap holes #1 to #3 using factory screw and supplied 1-1/2" washers (018066). Loosely secure at this point.



4. Using a bubble level or square, ensure that the mud flap is level. Viewing the vehicle from the back, the outer edge of the mud flap should appear parallel to the tires.
5. Carefully tighten all fasteners. Ensure that the mud flap has remained level.
6. For mud flaps with full liner, drill 1/4" hole through mud flap hole #5 into plastic molding (#11)
For mud flaps with half liner, drill 1/4" hole through mud flap hole #13 into plastic molding (#14)
7. Secure flap to plastic liner with a machine screw (012022), 2 stainless steel washers (018031), a lock washer (024001), and a hex nut (025003).
8. Drill 1/4" hole through mud flap hole #6 into plastic molding (#12)
9. Install spring nut on hole #12 on plastic liner (see diagram).
10. Secure using bolt (016041) and 1-1/2" flat washer (018066).
11. Repeat procedure on passenger side.



Please check out our YouTube channel to see an install video for this application.

