



Mud Flap Mounting Bracket Set

Universal, 12", 5/8" Offset

Mounting Diagram & Instructions

Part #756455

IMPORTANT:

The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.

TOOLS REQUIRED:



Phillips Screw
Driver



Electric or re-chargeable
1/2" or 3/8" drill.



1/4" Drill bit



3/8" Socket Driver

KIT CONTAINS: PARTS BAG #756455

a) (1) Offset Flap, DS
12"x5/8"
Part # 755614



b) (1) Offset Flap, PS
12"x5/8"
Part# 755615



c) (2) Back Strip, 12"x2"
Offset Flap
Part# 755611



d) (8) Mach.Screw
8-32 x 1/2"
Part #012031- SS



e) (8) Tek Screw,
1/4" x 1 1/4", SS
Part #010011




f) (8) Washer, SS
0.281 x 1" x 18ga
Part #018028



INSTRUCTIONS:

- Before you install your Mud Flap Set, see the Diagram and parts list for all necessary parts.
Cut protective plastic and peel away from stainless steel.
Start on Driver side.
- Cut the optional rubber flap to the required height, Minimum 11- 5/16" (See Diagram #1)
- Lay upper panel on the cut rubber flap and drill four 1/4" (4) Holes from the panel holes through the rubber flap. (See Diagram #2)
- Fasten the panel and the back strip to the rubber flap with the four (4) Cap screws. (See Diagram #3)
- Square the flap with the tire while holding the flap up against the wheel well and the offset flange tuck underneath the wheel well. (See Diagram #3)
- Locate the center of the wheel well or wheel flare on the back side of the stainless steel panel and drill four 1/4" holes from 'A' to 'D' on the stainless steel panel only.



NOTE: DRILL WITH CAUTION, DO NOT DRILL THROUGH THE WHEEL WELL OR WHEEL FLARE.



- Secure the flap with four flat washers and four TEK screws on Hole A to D.
- Repeat procedure for the passenger side.

