

**IMPORTANT:**

*The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.*


**TOOLS REQUIRED:**




Electric or re-chargeable  
1/2" or 3/8" drill.



5/16" drill bit



1/2" wrench  
and socket wrench



7/32" wrench  
or socket wrench



Clamp

**KIT CONTAINS: PARTS BAG #755553**

a) (1) Flap Assembly,  
Rear, DS



b) (1) Flap Assembly  
Rear, PS



c) (14) Tek Screw  
SS, 1/4" - 14 x 1.25"  
Part #010011



d) (14) Flat Washer  
0.281" x 1.00"  
Part #018028



e) (2) Mount Bracket  
Part #755571



f) (12) Flat Washer  
0.313 x 0.688"  
Part #018004



g) (8) Nylock Nut  
1/4" - 20  
Part #025004



h) (4) Capscrew  
1/4" - 20 x 1"  
Part #014007



i) (4) Carriage bolt  
1/4" - x 20 x 3/4"  
Part #014002



j) (2) Sht Metal Screw  
#10x1.25"  
Part #010017



k) (2) Flat Washer  
0.203" x 1.00"  
Part #018031



**INSTALLATION**

*For ease of installation, it is suggested that the wheel be removed.*

1. Before you install your precision mud flap, see the diagram and parts list for all necessary parts. Start on the driver's side.
2. Bolt the offset bracket to the long bracket with 2 Carriage bolts 1/4" x 3/4", 2 small washers 1/4" and 2 lock nuts 1/4". Finger tight only at this point.
3. Remove the factory screw #9 on the wheel well as shown on the diagram and replaced with a washer & #10 sheet metal screw on hole #6, loosely secure at this point.
4. Square the flap with the tire and push the flap up against the wheel well.
5. Raise the offset bracket up against the bottom of the truck box frame and clamp the offset bracket in place.




Diagram #1

6. Drill a 5/16" hole (2 places) from the top holes on the offset bracket through the truck box frame on the flange and secure the bracket to the flange with 2 capscrews 1/4" x 1", 4 small washers 1/4" and 2 lock nuts 1/4" (see diagram). Now secure all the fasteners.
7. Fasten the flap with 7 tek screws and 7 flat washers on holes #1 to #5, #7 and #8. **\*Note\*** Ensure that the screws #7 and #8 are fastened to the wheel well (See Diagram).

**Check all fasteners for tightness. Repeat procedure on the other side.**